

Outdoor Shower

simple installation manual for Hot and Cold Water with embedded C-box

① Confirm positions for embedded C-box and shower place (distance btw them is 750mm), then dig holes based on C-box size.

vertical to shower place
for cold water
for hot water
shower place

② Connect hot and cold water pipes to the embedded C-box, make sure no leaking.

4pcs M8*80 expansion screws
145*145mm

③

middle line
Bottom line

Make sure C-box is vertical and centered to you. Tighten up C-box to hole bottom with 4pcs M8 expansion screws, make sure floor tile must be higher than bottom line and lower than middle line of C-box.

④ Throw out C-box cover and plugs for hot and cold water outlets. Cut the extra top part of C-box.

8mm 6-angle tool

⑤ Insert lower pipe to the C-box, connect bottom plate to C-box with 4 screws, then push down the bottom decorated cover to floor.

hot water
cold water
5mm 6-angle tool

⑥ Insert upper pipe into the lower pipe, match back lines on two pipes together to be one rectangular, and lock screw in back pipes to get installation done.

Connect handshower with flexible hose if have. (if items have spout, pls note we already got it installed.)

2.5mm 6-angle tool
750