




Service







94148000

hansgrohe








- D** Das Reinigen wiederholen, wenn im Laufe der Zeit der Auszug schwergängig wird.
- F** Répétez cette action torsque l'extraction devient difficile.
- GB** Repeat cleaning when pull out will be heavy.
- I** Questa azione di pulizia deve essere ripetuta in caso, con il passare del tempo, l'apertura della placca diventi difficoltosa.
- E** Repetir la limpieza, cuando el tiempo aumenta la resistencial al extraerlo.





- NL** U kunt deze handeling herhalen indien na verloop van tijd het uittrekken van de douche wat zwaarder gaat.
- DK** Venligst gentag rengøringen såfremt udrækket med tidnbliver trægt.
- P** Limpe ontra vez se for ainda aifical de puxar can o tempo.
- PL** Powtórzyć czyszczenie w przypadku, gdy z upływem czasu pojawią się trudności z wyciąganiem węża.





hansgrohe

Hansgrohe · Postfach 1145 · D-77761 Schiltach · Telefon +49 (0) 78 36/51-1282 · Telefax +49 (0) 7836/511440
E-Mail: info@hansgrohe.com · Internet: www.hansgrohe.com

09/2007
9.08088.01