











CAR02X Instruction Manual





| | |
|--|---|
| <p>A</p>  <p>x4</p> | <p>B</p>  <p>ST4x35</p> <p>x4</p> |
| <p>C</p>  <p>x4</p> | <p>D</p>  <p>x1</p> |
| <p>E</p>  <p>x2</p> | <p>G</p>  <p>x1</p> <p>4mm</p> |
| <p>F</p>  <p>3mm</p> <p>x1</p> | <p>G</p>  <p>x1</p> <p>4mm</p> |

