

















Alterna

Montagehandleiding Free Basic Pivot Draaideur 1626641, 1626623, 1626642




LET OP! Gehard veiligheidsglas. Voorzichtig hanteren!
Zet de glaswand niet op een van de punten,
want daardoor kan hij breken.








<p>1</p>  <p>x1</p>	<p>2</p>  <p>x2</p>	<p>3</p>  <p>x1</p>	<p>4</p>  <p>x6</p>	<p>5</p>  <p>ST4x40</p> <p>x6</p>	<p>6</p>  <p>x6</p>
<p>7</p>  <p>x1</p>	<p>8</p>  <p>x1</p>	<p>9</p>  <p>x1</p>			
					

①








	X(mm)
1626641	760-800
1626623	860-900
1626642	960-1000


②




3




a





b









c







4






5




6





7






8




9



10





11

