







MONTAGEHANDLEIDING  
INSTRUCTION DE MONTAGE  
MONTAGEANLEITUNG


# VM Origine Swing Easy 224113 - 224114






DRAAIDEUR / PORTE PIVOTANTE / DREHTÜR








|          |                   |         |          |          |          |               |          |          |                    |
|----------|-------------------|---------|----------|----------|----------|---------------|----------|----------|--------------------|
| 4<br>x2  | 5<br>x6<br>ST4X40 | 6<br>x6 | 15<br>x1 | 23<br>x3 | 27<br>x1 | 28a/b/c<br>x1 | 29<br>x4 | 30<br>x1 | 31<br>x4<br>ST4X12 |
| 32<br>x1 | 33<br>x1          |         |          |          |          |               |          |          |                    |











1




2





3






4





7



8

