







MONTAGEHANDLEIDING
INSTRUCTION DE MONTAGE
MONTAGEANLEITUNG











Intro Star Easy
Intro Star ALU Easy


224096 - 224097
224106 - 224107




VOUWDEUR / PORTE PLIANTE / FALTTÜR





4  x6	5G/W  x14	6  ST4x40 x6	10G/W  x1	25a/b  x2	27  ST4x8 x8	28G/W  x1
30  x1	31a/b  x1	32a/b  x1				




①





②




3




4











5






6




7




8




9




a1




a2




b




c




10




a1




a2





b1





b2



11



12



13

